

1. INTRODUCTION

This document describes how to configure the CQM II for Infinite Splice operation on APT-5A and APT-5A HF Terminating Machines with Infinite Splice tooling installed.



NOTE





For additional information, reference the following related documents: Customer Manual 409-10100: Crimp Quality Monitor II, Customer Manual 409-32025: Crimp Quality Monitor II (CQM II) Sequencing Guide, and Customer Manual 409-32022: AMPLIVAR* Product Terminators APT-5A, APT-5A DC, and APT-5A HF and APT-5E, APT-5E DC, and APT-5E HF.

2. SOFTWARE REQUIREMENTS

CQM II Software Version: 3_00_34 or higher

3. HOW TO CONFIGURE CQM II

3.1. To Enable the Infinite Splice Mode

1. Pull down the menu by touching the Menu Collapse Arrow  on the upper right corner of the screen.
2. Select the Tools Menu  to go to the Control Panel.
3. Scroll to the bottom of the Control Panel until you see .
4. Select .
5. Then, select Infinite Splice .



NOTE

When Infinite Splice is selected, the Wire Stuffer radio button will be automatically selected also. This is because Wire Stuffer and Infinite Splice share the same output. In actuality, Wire Stuffer functionality is disabled when Infinite Splice is enabled.

The System Settings screen should appear as shown below:




Figure 1

6. Select “Restart”




Figure 2

7. When the following screen appears, power off the machine as requested. This will finish the configuration for the Infinite Splice mode of operation.




Figure 3

3.2. To Enable the “Shear” Option in Infinite Splice Mode

Whenever a part is created or edited, a “Shear” option may be enabled.



NOTE

The default setting for Infinite Splice is to NOT Shear; i.e., after processing, parts will remain on a continuous strip.

1. An example of enabling the “Shear” option is shown in Figure 4.
 - a. A Part Number identified as “1-SHEAR” in Sequence Position 2 has been created.





Figure 4

- b. By using the  tab on the Task Bar (located at the bottom of the screen), the option to “Shear” the selected Part Number can be enabled (see Figure 5).




Figure 5