

Installation Instructions for 4.3-10 connector 2081970

- 1 STANDARD STRIPPING DIMENSION
- 2 CUT OFF AT THE MIDDLE OF THE CREST
- 3 USE CUTTING TOOLS OR KNIFE STRIP THE JACKET



1. 标准剥线长度
1. Standard stripping dimension

2. 从波峰处切开
2. Cut off at the middle of the crest

3. 使用剥线工具或美工刀切除外皮
3. Use cutting tools or knife strip the jacket

- 4 GET THE REQUEST DIMENSION, CHAMFERING AND DEBURR AT INNER CONDUCT, BRUSH THE CHIPPING.
- 5 SPIN THE CONNECTOR FERRULE, FINISH WHEN THE CONNECTOR FLAT ALIGNED WITH THE OUTER CONDUCT.
- 6 MATCH THE CONNECTOR, HOLD THE HEAD AND SPIN THE FERRULE, TORQUE 18-22N.M



4. 截取合适的长度，去除毛刺，内导体倒角
4. Get the request dimension, chamfering and deburr at inner conduct, brush the chipping

5. 旋转装入接头尾套，接头端面对齐外导体。
5. Spin the connector ferrule, finish when the connector flat aligned with the outer conduct

6. 旋入接头头部，尾部旋转紧固接头
6. Match the connector, hold the head and spin the ferrule, torque 18-22N.M