

## Installation Instructions for 4.3-10 connector 2081971

- **1 STANDARD REQUIREMENT FOR STRIPPING**
- 2 CUT THE SHEATH USE STRIP TOOL OR KNIFE
- 3 REMOVE THE SHEATH AND DIELECTRIC, GET THE SUITABLE DIMENSION.



- 1. 剥线标准要求
- 1, Standard requirement for stripping
- 2、剥去外护套 2. Cut the sheath use strip tool of knife
- 3. 去除外护套和去除绝缘,得到合适尺寸 3. Remove the sheath and dielectric, get the suitable dimension

- PUT ON THE O-RING AND DEBURR 4
- INSTALL THE CONNECTOR FERRULE, FIX ON THE 1<sup>ST</sup> CORRUGATE SLOT 5
- 6 INSTALL THE CONNECTOR HEAD, TORQUE REFERENCE 13+/-2N.M



- 4. 安装O型圈, 去除毛刺 4. Put on the O-sealing and deburr
  - 1st corrugate slot
- 6. 安装头部,参考力矩13±2N.M 5. Install the connector ferrule, fix on the 6, Install the connector head, turgue reference 13±2N.M

© 2020 TE Connectivity family of companies All Rights Reserved I Indicates Change

\*Trademark. TE Connectivity, TE connectivity (logo), and TE (logo) are trademarks. Other logos, product, and/or company names may be trademarks of their respective owners.