



HYDRAULIC CRIMPING HEAD 69065



HEAD ASSEMBLY FITTING INSTRUCTIONS



ASSEMBLE HEAD SUB ASSEMBLY TO CYLINDER UNTIL TIGHT ENSURING THAT KEY ON RAM ALIGNES WITH KEYWAY ON CYLINDER HEAD.

CENTRE PUNCH THRU 5-40 TAPPED HOLE "ILLUSTRATED *" REMOVE THEAD ASSY AND DRILL .104" DIA HOLE .06" DEEP.

ENSURE THAT ALL PARTS ARE CLEAN, REASSEMBLE HEAD ASSEMBLY AND LOCK GRUB SCREW.