


SHELL SIZE	CONNECTOR POSITIONS		CLAMP ASSY†	SHELL SIZE	CONNECTOR POSITIONS		CLAMP ASSY†	SHELL SIZE	CONNECTOR POSITIONS		CLAMP ASSY‡
	HD-20	HD-22			HD-20	HD-22			HD-20	HD-22	
1	9	15	5205729	1	9	15	207467	2	15	26	5206471
2	15	26	5205730	2	15	26	207470	3	25	44	5206472 5745134
3	25	44	5205718	3	25	44	207345				
4	37	62	5205731	4	37	62	207473	4	37	62	5745081
5	50	78	5205732	5	50	78	207476	5	50	78	5745082

†Recommended only for HDP Connectors. ‡Recommended for HDE or HDP Connectors.

Figure 1

1. INTRODUCTION

This instruction sheet covers the installation of cable clamp assemblies for AMPLIMITE HD-20, HD-22, HDP, and HDE connectors. See Figure 1. Read this instruction sheet thoroughly before attempting to install the cable clamp assemblies.



Figures and illustrations are for reference only and are not drawn to scale.

Reasons for reissue of this instruction sheet are provided in Section 4, REVISION SUMMARY.

2. DESCRIPTION

There are three types of cable clamp assemblies covered in this instruction sheet:

- Straight/45° one-piece
- Straight/90° one-piece
- Straight/90° two-piece

The clamp assemblies are held together by screws supplied in the kit. The cable clamp assemblies can be used on either plug or receptacle connectors.




Figure 2

3. ATTACHING CABLE CLAMP ASSEMBLIES

Insert the contacts into the connector as described on Instruction Sheet 408-7514, which is packaged with the connector. Select the proper cable clamp from the table in Figure 1.

3.1. Straight/45° One-Piece Assembly

1. Position the flange of the connector into the cable clamp slot shown in Figure 1. Place the longer row of contact positions in the bottom so that the wires are not pinched when the clamp is closed.
2. Position the cable in the strain-relief channel.
3. Position the strain-relief gate in the clamp for either a 45° or a 180° outlet. The gate must enter the gate slot in the clamp.
4. For Size 1 or 2 shell, place the brass shim between the gate and the screw channel. See Figure 2.
5. Position the cable in the cable channel and close the clamp.
6. Secure the clamp with self-tapping screws, as follows:
 - 1 screw for shell size 1
 - 2 screws for shell size 2
 - 3 screws for shell sizes 3, 4, or 5
7. Secure the gate screw or gate setscrew. Thread the gate screw in until the gate is firmly holding the cable. *Do NOT overtighten the screw.*

NOTE Size 1 and 2 shells use a black gate screw. Size 3, 4, and 5 shells use a gate setscrew and nut instead of the black gate screw.

8. Push a small amount of wire into the clamp to provide strain relief on the wire bundle. Thread the gate screw in until the gate is firmly holding the wires. *Do NOT overtighten the screw.*

3.2. Straight/90° One-Piece Assembly

A carrier strip with strain-relief gates is packaged with each assembly. The size of the gate used depends on the diameter of the cable. Discrete-wire bundles use blank gates; jacketed cables use curved gates.

1. Remove the proper gate from the carrier strip.
2. Insert the connector into the clamp with the longer row of contacts in the bottom. Position the cable in the strain-relief channel.
3. Insert the gate into the cable clamp slot, as shown in Figure 1.

NOTE The largest blank (unused outlet) can be installed with either flat side in the slot. The other blank gates should be installed with the strain-relief section touching the cable.

4. Position the cable over the gate and close the cable clamp.
5. Thread the screws into the holes in the cable clamp and tighten them to complete the assembly.

3.3. Straight/90° Two-Piece Assembly

1. Lay the connector and cable in one half of the clamp. Thread a cable tie through the internal tie openings and secure the cable to the clamp as tightly as possible.
2. Install the other clamp half, and captivate the two mounting screws. See Figure 1.
3. Secure the assembly with the fillister-head screws and hex nuts supplied.

CAUTION If the wire bundle is dressed at 90°, use cable ties through the external tie openings after the clamp halves are assembled. The cable tie knots should be tucked into the cable clamp for a neater appearance.

4. REVISION SUMMARY

- Update document to corporate requirements
- New logo