


©₽



A-MP* EXTRACTION TOOL CATALOG NO. 91011-1 FOR AMP-TAB* MALE TAB TERMINALS

IS 7	111
RELEASED	6-28-63
REVISED	7-16-65



*Trademark of AMP Incorporated

FIG. 1

1. This Tool (see Figure 1) is used to extract AMP-TAB Male (Tab) Terminals from AMP-TAB Dual (Two-Tab) Connectors. Read these instructions carefully before using the Tool.

2. EXTRACTION PROCEDURE


(a) Insert Releasing Tip into back (wire-entry side) of Con-

closest to the Tab Terminal to be extracted.

(b) Keeping Tool perpendicular to Connector, push Tool into Cavity until it bottoms against Connector, See Figure 3.

nector as shown in Figure 2. Make sure Releasing Tip is

(c) With Tool bottomed against Connector, pull back on Tool and Wire at the same time to remove Tab Terminal.






FIG. 3